

# MAGIC WAND

**For the delight and amusement of all people age 14 and over. For indoor use only.**

**Receiver Rating: Max 10A / 1250W Resistive Max 6A 650W Tungsten.**

**Do not exceed rated capacity.**

## A. OPERATION

1. Unscrew to open the battery compartment cover and insert 2 x AA batteries (not included) into the battery compartment. Align "+" and "-" as marked inside the battery compartment.
  2. Screw to close the battery compartment cover.
  3. Plug the receiver into a nearby working outlet.
  4. Plug the light string into the receiver.
  5. Wave the magic wand and the light and sound will come on. The light string will turn on.
  6. Wave the magic wand again to turn off the item and the light string will turn off.
- The item works with any LEDs or incandescent lights.

Manual Operation

Press the button on the side on the receiver to turn the lights on and off .

Note: The wand and receiver are paired. If the button on the receiver is pressed for too long, it will cancel the pairing. If this happens, follow these steps:

- Hold the button for 3 seconds, the LED indicator will flash slowly.
- Wave the wand, when the indicator light on the receiver is steady, it means the pairing is successful.

## B. TROUBLESHOOTING

PROBLEM	LIKELY CAUSE	SOLUTION
No light or sound	Batteries not inserted correctly	Make sure to align the "+" and "-" as marked inside the battery compartment
	No power	Make sure the receiver is plugged into a working outlet
	Batteries exhausted	Change to new batteries
	Wand and receiver not paired	Refer to point 5 in "Operation" to re-pair

## C. CARE INSTRUCTIONS

1. Do not expose this item to moisture or outdoors. This item is for indoor use only.
2. Before using or reusing, inspect product carefully. Discard any products that have cracks in enclosure or exposed wire.
3. When storing the product, carefully remove from the current location to avoid any undue strain or stress on the conductors, connections and wires.
4. When not in use, store neatly in a cool, dry location protected from sunlight and heat.
5. If necessary, clean product by wiping with a soft, dry cloth. Do not use any corrosive cleanser or chemical solution on this item.

## D. BATTERY INSTRUCTIONS

1. Do not dispose batteries in fire. Batteries may explode or leak.
2. Do not mix old and new batteries.
3. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
4. Replace batteries of the same brand.
5. Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
6. Remove fully discharged batteries immediately.
7. Remove all the batteries for storage of the unit to avoid battery leakage.
8. Batteries should be recycled or disposed of as per state and local guidelines.

*The following is only applicable to customers in the USA:*

### FEDERAL COMMUNICATIONS COMMISSION, PART 15:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Made by TERISMOND

Email: [sales@terismond.com](mailto:sales@terismond.com)